XIKAR PuroTemp™ Digital Gauge Hygrometer

Instructions for Use

XIKAR PuroTemp™ Digital Gauge Hygrometer / Thermometer will accurately report humidity to +/- 2% at 70% RH (relative humidity) and temperature to 1 degree Fahrenheit / Celsius. To activate this unit, simply remove the vinyl tab located in the battery door on the bottom of the unit. The LED screen should turn on and show humidity and temperature readings.

If the screen does not turn on, remove the battery by opening the cover located on the back of the unit. Make sure the battery is installed properly and makes contact with the silver metal contact. If the unit will not turn on, replace the battery.

To switch between Celsius and Fahrenheit display, simply press the C / F button located on the side of the hygrometer.